



assembly instructions

10072019




1

connect poles and insert the pole tip into the flag sleeve




2

IMPORTANT ► push the pole to the very end of sleeve



3

tension flag and place on your chosen hardware



EXTEND THE LIFE OF YOUR FLAG AND HARDWARE

ensure your flag flies freely, it should not be impeded by surrounding structures such as fences, trees and walls etc...

tip

increase the colour fastness and life span of your flag by not flying it 24/7

bring your flag in when not in use - a good time is at the end of your business day

wind warning



double sided flags should not be flown in winds exceeding 35kmh



single sided flags should not be flown in winds exceeding 50kmh